



GAMING KEYBOARD

HK75



WIRED

EN User manual
DE Benutzerhandbuch
FR Manuel utilisateur
IT Manuale d'uso
ES Manual de usuario
NL Handleiding
PL Instrukcja obsługi
RO Manual de utilizare
HU Használati utasítás
BG Ръководство за употреба
CS Uživatelský manuál
SK Používateľská príručka

LV Lietotāja rokasgrāmata
LT Vartotojo vadovas
EST Kasutusjuhend
TR Kullanım kılavuzu
UA Посібник користувача
FI Ohjekirja
SWE Användarmanual
NO Brukermanual
DAN Brugermanual
AR دليل الاستخدام
HE מודריך למשתמש


PACKAGE CONTENT

- Keyboard
- Detachable USB-A to Type-C cable
- Keycap and switch puller
- User manual



PRODUCT OVERVIEW



1. OEM profile keycaps
2. Functional keys
3. Adjustable RGB lighting effects
4. Side RGB backlight
5. LED indicators
6. Volume knob
7. Win/IOS switch
8. USB-A to Type-C cable
9. Feet
10. Rubber pads



7. Win/IOS switch

Use to switch between two operating system modes - Windows® or macOS®

The function (F) keys and Win/Alt keys behavior will change.



6. Volume knob

Mute Press once
Volume -/+ Rotate

Press and hold for 2 seconds to switch between **Volume Control** and **Backlight Control**, 3 indicators will flash three times.

Knob default function is Volume Control

Volume Control:
Anti clock-wise to Volume -
Clock-wise to Volume +
Press to mute

Backlight Control:
Brightness- - turn anti clock-wise
Brightness+ - turn clock-wise
Press once to change lighting effect

5. LED indicators

- CAPS Caps Lock
- WIN Win key lock
- SCR Scroll Lock

HELLYBERRY® SOFTWARE

For access to a wide range of customization options, download the software from the official web page: <https://hellyberry.eu/pages/downloads>



Scan to download

SOFTWARE REQUIREMENTS

Software is available on Windows® only.
Platform: Windows® 10/11 (64-bit).
500Mb of free data storage space for installation.

HOTKEYS FOR WINDOWS®

Key Combination	Function
FN + F1	Display brightness -
FN + F2	Display brightness +
FN + F3	My PC
FN + F4	Show desktop
FN + F5	Media player
FN + F6	Previous track
FN + F7	Play/Pause
FN + F8	Next track
FN + F9	Mail
FN + F10	ScrLk
FN + F11	Pause
FN + F12	Keys lock
FN + Win	Win key lock
FN + PgUp	Home
FN + PgDn	End

GLOBAL HOTKEYS

Key Combination	Function
FN + ESC	Restore to factory settings Press and hold for 3sec
FN + W	WASD to Arrows swap Press and hold for 3sec

HOTKEYS FOR MACOS®

Key	Function
F1	Display brightness -
F2	Display brightness +
F3	This computer
F4	Back to desktop
F5	Search
F6	Previous track
F7	Play/Pause
F8	Next track

RGB BACKLIGHT HOTKEYS

Key Combination	Function
FN + ↑	Backlight brightness+
FN + ↓	Backlight brightness-
FN + →	Backlight speed+
FN + ←	Backlight speed-
FN + Backspace	Switch backlight effect
FN + Enter	Switch side light effect
FN + \ /	Switch backlight color
FN + ; ,	Side light brightness-
FN + ' "	Side light brightness+
FN + Delete	Enable/disable backlight
FN + Space	Reset to default (hold for 3 seconds)

! Please reset the keyboard settings using the Fn+Esc (press and hold for 3 sec) combination before first use.

EN HOW TO USE

Connect the keyboard to a USB-A port on your computer.
The OS will detect your keyboard automatically.

DE SO VERWENDEN SIE DIE TASTATUR

Schließen Sie die Tastatur an einen USB-A-Anschluss Ihres Computers an.
Das Betriebssystem erkennt Ihre Tastatur automatisch.

FR COMMENT UTILISER

Connectez le clavier à un port USB-A de votre ordinateur.
Le système d'exploitation détectera automatiquement votre clavier.

IT COME UTILIZZARE

Collega la tastiera a una porta USB-A del tuo computer.
Il sistema operativo rileverà automaticamente la tastiera.

ES CÓMO UTILIZAR

Conecta el teclado a un puerto USB-A de tu computadora.
El sistema operativo detectará automáticamente el teclado.

NL HOE TE GEBRUIKEN

Sluit het toetsenbord aan op een USB-A-poort van uw computer.
Het besturingssysteem detecteert je toetsenbord automatisch.

PL JAK UŻYWAĆ

Podłącz klawiaturę do portu USB-A w komputerze.
System operacyjny automatycznie wykryje klawiaturę.

RO CUM SE UTILIZEAZĂ

Conectați tastatura la un port USB-A al computerului dumneavoastră.
Sistemul de operare va detecta automat tastatura.

HU HASZNÁLATI ÚTMUTATÓ

Csatlakoztassa a billentyűzetet a számítógép USB-A portjához.
Az operációs rendszer automatikusan felismeri a billentyűzetet.

BG КАК ДА ИЗПОЛЗВАТЕ

Свържете клавиатурата към USB-A порт на вашия компютър.
Операционната система автоматично ще открие вашата клавиатура.

